

In [1]:



```
# Imports
import pandas as pd
import matplotlib.pyplot as plt
%matplotlib inline

# Set Matplotlib size

plt.rcParams["figure.figsize"] = [12, 7.5]

# Read in only relevant data from .txt files and give names to columns.

df1 = pd.read_csv('MS_AGILKIA.txt', sep = '\t', header = 14, usecols = [1,2,3])
df1.columns = ['Molecular Mass', 'Scan 1 Intensity', 'Scan 2 Intensity']

df2 = pd.read_csv('MS_ABYDOS2.txt', sep = '\t', header = 14, usecols = [1,2,3])
df2.columns = ['Molecular Mass', 'Scan 1 Intensity', 'Scan 2 Intensity']

# Select the rows with only one measurement and apply the scaling factors.
# Then sum the rows with two measurements (summing all rows at this point
# works because the rows with one measurement have 0 in the other column).

df1.iloc[0:12,1:2]=df1.iloc[0:12,1:2]*1.35
df1.iloc[77:,2:]=df1.iloc[77:,2:]*1.35
df1['Sum']=df1['Scan 1 Intensity']+df1['Scan 2 Intensity']

df2.iloc[0:12,1:2]=df2.iloc[0:12,1:2]*1.47
df2.iloc[77:,2:]=df2.iloc[77:,2:]*1.47
df2['Sum']=df2['Scan 1 Intensity']+df2['Scan 2 Intensity']


# Plot data and label as appropriate

plt.bar(df1['Molecular Mass'],df1['Sum'],label = 'Agilkia')
plt.bar(df2['Molecular Mass'],df2['Sum'], label = 'Abydos')
plt.title('Ptolemy Mass Spectrometer Scans')
plt.xlabel("Molecular Mass (m/z)")
plt.ylabel("Intensity")
plt.grid()
plt.legend(loc = 'upper right')
```

Out[1]:

<matplotlib.legend.Legend at 0x289833d47b8>





In [2]:

```
# Agilkia CO & CO2  
print(df1.iloc[15:17])  
print(df1.iloc[31:33])
```

	Molecular Mass	Scan 1 Intensity	Scan 2 Intensity	Sum
15	28	91.0	40.0	131.0
16	29	47.0	34.0	81.0
	Molecular Mass	Scan 1 Intensity	Scan 2 Intensity	Sum
31	44	53.0	40.0	93.0
32	45	310.0	201.0	511.0

In [3]:

```
# Abydos CO & CO2  
print(df2.iloc[15:17])  
print(df2.iloc[31:33])
```

	Molecular Mass	Scan 1 Intensity	Scan 2 Intensity	Sum
15	28	2.0	2.0	4.0
16	29	3.0	3.0	6.0
	Molecular Mass	Scan 1 Intensity	Scan 2 Intensity	Sum
31	44	27.0	28.0	55.0
32	45	3.0	5.0	8.0

In [4]:



```
Ag_CO = 131+81
Ag_CO2 = 93+511
Ab_CO = 4+6
Ab_CO2 = 55+8

Ag_ratio = Ag_CO/Ag_CO2
print('The CO:CO$_2$ ratio for Agilkia is 1:',Ag_ratio)

Ab_ratio = Ab_CO/Ab_CO2
print ('The CO:CO$_2$ ratio for Abydos is 1:',Ab_ratio)
```

The CO:CO\$_2\$ ratio for Agilkia is 1: 0.3509933774834437
The CO:CO\$_2\$ ratio for Abydos is 1: 0.15873015873015872

In [5]:



```
# Select the sums for the two molecular masses of CO at Agilkia and add them together,  
# then do the same for CO2.

Ag_CO = df1.iloc[15,3]+df1.iloc[16,3]
Ag_CO2 = df1.iloc[31,3]+df1.iloc[32,3]

# Take these values and divide them, printing the answer.

Ag_ratio = Ag_CO/Ag_CO2
print('The CO:CO$_2$ ratio for Agilkia is',Ag_ratio)

# Repeat the process for Abydos

Ab_CO = df2.iloc[15,3]+df2.iloc[16,3]
Ab_CO2 = df2.iloc[31,3]+df2.iloc[32,3]

Ab_ratio = Ab_CO/Ab_CO2
print ('The CO:CO$_2$ ratio for Abydos is',Ab_ratio)
```

The CO:CO\$_2\$ ratio for Agilkia is 0.3509933774834437
The CO:CO\$_2\$ ratio for Abydos is 0.15873015873015872